

Press Mounting Plate Into The Cable With Thumb And Hold Index Finger Underneath To Close Bottom Opening. Continue This Hold When Sliding Cleat Onto Mounting Plate And When Dropping Top Plate Into The Center (Between Cable And Cleat). The Lip Of The Top Plate Should Fit Into The Notch Of The Mounting Plate. Finger Tighten Fastener Against Top Plate, Then Use Screwdriver To Secure.

