

USE NEEDLE NOSE PLIERS TO INSERT SPADES OR OPEN UNIT BY
INSERTING A FLAT HEAD SCREW DRIVER AND TWISTING UNTIL
UNIT SEPARATES

BE CAREFUL WHEN OPENING OR SPRING COULD POP OFF

SPADES SHOULD LOCK IN POSITION AS SHOWN

